



These Instructions Must be Read by the User Before Using the Electric Screwdriver

The power tools must be operated correctly according to the manufacturer's or owner's operating instructions, which are available on request if required

**CHECK that all persons and animals are clear of the work area
Loose clothing, sleeves etc should be avoided. Long hair should be tied back. Wear overalls wherever possible
Wear personal protective equipment as necessary; safety goggles or glasses when there is danger of flying debris**

CHECK that the screwdriver bits supplied by the Hire Company are of the specified type, size and are in good condition

CHECK before starting that the material to be worked on is securely held or clamped

CHECK that there are no nails, staples etc in the wood that could jam or damage the tool

DO NOT use the bit if it becomes broken or chipped. Remove it and replace it with a new one

**Isolate the power supply before replacing a bit or before making adjustments to the tool
When operating the power tool hold it firmly with both hands using the correct handles and stand firmly on both feet**

DO NOT force the tool. An even pressure reduces the chances of an accident due to jamming or breakage of the bit

DO NOT carry the tool with your fingers on the trigger or button

ALWAYS use the carrying holster provided when moving around

DO NOT leave the tool unattended without switching off

Vibration from the tool can cause 'VIBRATION WHITE FINGER' and eventually other damage to hands and arms. Keep your hands warm at all times. Gloves can reduce vibration. If your hands start to feel numb, stop work and exercise your fingers to restore circulation. Limit your time using the tool as much as possible.

CHECK regularly that all ventilation grills or holes on motor housings are clear and free from dirt.

DO NOT use electrical tools in damp, wet or flammable conditions.

If the automatic cut-out operates, allow the motor to cool before re-starting.

ENSURE that the power pack is fully charge before the work commences.

DO NOT attempt repairs. Contact the Hire Company.